




3. Flow Chart of Troubleshooting


3-1 BASEBAND

3-1-1. Power ON













3-1-2. Initial











3-1-3. Sim Part









3-1-4. Charging Part












3-1-5. Microphone Part







3-1-6. Speaker Part











3-1-7. LCD








3-1-8. Camera






3-2. RF


3-2-1. GSM900 Receiver

CONTINUOUS RX ON
RF INPUT : 62CH
Cell power : -50dBm




3-2-2. DCS Receiver


CONTINUOUS RX ON
RF INPUT : 698CH
Cell power : -50dBm




3-2-3. PCS Receiver

CONTINUOUS RX ON
RF INPUT : 698CH
Cell power : -50dBm







3-2-4. GSM900 Transmitter






3-2-5. DCS Transmitter



3-2-6. PCS Transmitter







3-2-7. Bluetooth Part

